


# Nikon coolpix S560 notes



## Auto Scene Mode

1. Hit the  button and choose the scene icon with a love heart


This mode will work for most situations. Leave it in this mode and the camera decides everything for you.

## Shooting Mode

1. Hit the  button and choose the green camera icon.

In this mode you must set the White balance (ie tell the camera what the main light source is), ISO sensitivity, and how the shutter button releases (continuous, single, multi-shot 16 etc).

## Sport Mode

1. Hit the  button and choose the scene icon.
2. Hit "MENU" and select the running man icon.

This mode sets the camera to shoot at 1/500<sup>th</sup> of a second shutter speed and is good for kids running around etc

## Continuous, Single and 16-multi shot

1. Hit the menu button and look for either the "continuous or single" option. Switch to desired shutter mode

Single = one press takes one shot


Continuous = holding the shutter button down keeps the camera clicking for several shots

16-multi = one press takes 16 small images combined in one frame – great for analysing movement.

## Use the flash during the day

While in shooting mode force the flash on by pushing this button and choosing the lightning arrow icon. Using the flash during the day for portraits fills in ugly shadows on the face.

## Apply D-Lighting to images

1. Hit the  button and choose the image you want to fix.
2. Hit "MENU" and select D-lighting option

This will lift shadows and bring some detail back to white washed parts of the image.

## Really fast action shots

While in shooting mode choose an ISO sensitivity of 800 or more to force the shutter speed higher.

hing@hanganimage.com

[www.hanganimage.com](http://www.hanganimage.com)